


**CM** Breakdown and Part list  
*Schéma et le liste de pièce*

Gas Engine / *Moteur à essence*  
(GE5.5, GE6.5, GE9.0, GE11, GE13)




Tel.: 1-877-405-2626, Fax: 1-877-405-8686  
Web site: [www.cm-equip.com](http://www.cm-equip.com)  
E-mail: [info@cm-equip.com](mailto:info@cm-equip.com)

# 1. Crankcase / Carter de moteur




No.	Pièce / Part
.ge0101	Crankcase
.ge0102	Oil seal
.ge0103	Radial ball bearing
.ge0104	Governor arm shaft
.ge0105	Lock pin
.ge0106	Plain washer
.ge0107	Drain plug bolt
.ge0108	Drain plug washer
.ge0109	Governor gear kit
.ge0110	Governor shaft
.ge0111	Governor shaft clip
.ge0112	Governor
.ge0113	Plain washer 6
.ge0114	Radial ball bearing
.ge0115	Governor shaft oil seal

## 2. Crankcase cover / Couvercle de carter




No.	Pièce / Part
.ge0201	Crankcase cover
.ge0202	Oil seal
.ge0203	Radial ball bearing
.ge0204	Oil filler cap
.ge0205	Seal
.ge0206	Dowel pin
.ge0207	Crankcase gasket
.ge0208	Radial ball bearing

### 3. Crankshaft piston & connecting rod / *Piston de vilebrequin et bielle*




No.	Pièce / Part
.ge0301	Crankshaft assly
.ge0302	Woodruffkey
.ge0303	Piston ring set
.ge0304	Connecting rod assly
.ge0305	Piston pin clip
.ge0306	Piston
.ge0307	Piston pin clip
.ge0308	Balance shaft

## 4. Cylinder head & cover / Culasse & couvercle




No.	Pièce / Part
.ge0401	Cylinder head assly
.ge0402	Stud bolts
.ge0403	Dowel pin
.ge0404	Spark plug
.ge0405	Cylinder head gasket
.ge0406	Head cover
.ge0407	Head cover gasket
.ge0408	Breather tube
.ge0409	Cylinder head bolts
.ge0410	Lead wind cover
.ge0411	Head cover bolts
.ge0412	Stud bolts

## 5. Camshaft & valve rocker / Arbre a cames & culbuteur de soupape




No.	Pièce / Part
.ge0501	Camshaft assly
.ge0502	Valve teppet
.ge0503	Push rod
.ge0504	Push rod guide plate
.ge0505	Valve rocker
.ge0506	Rocker pivot pin
.ge0507	Pivot bolt
.ge0508	Pivot adjusting nut
.ge0509	Intake valve
.ge0510	Exhaust valve
.ge0511	Valve spring
.ge0512	In-valve spring seat
.ge0513	Ex-valve spring seat
.ge0514	Valve rotator
.ge0515	Ex-valve spring retainer
.ge0516	Guide oil seal

## 6. Recoil starter / Démarreur a rappel




No.	Pièce / Part
.ge0601	Fanhood
.ge0602	Recoil starter assly
.ge0603	Spiral spring
.ge0604	Reel
.ge0605	Returnt spring
.ge0606	Ratchet
.ge0607	Press spring
.ge0608	Ratchet guide
.ge0609	Set bolt
.ge0610	Rope
.ge0611	Plastic handle
.ge0612	Shroud comp
.ge0613	Bolt

## 7. Carburetor assembly / Carburateur




No.	Pièce / Part
.ge0701	Carburetor for engine
.ge0702	Carburetor for generator
.ge0703	Air cleaner gasket
.ge0704	Carburetor gasket
.ge0705	Connecting block
.ge0706	Inlet gasket
.ge0707	Check valve assly
.ge0708	Manual choke assly






## 8. Air filter / Épurateur d'air








No.	Pièce / Part
.ge0801	Air filter for engine
.ge0801a	Air filter element (A)
.ge0801b	Air filter element (B)
.ge0801c	Air filter element (C)
.ge0802	Air filter for generator
.ge0802a	Air filter element

## 9. Regulating control system / Système de commande de régulation



No.	Pièce / Part
.ge0901	Speed control assly
.ge0902	Speed control assly
.ge0903	Governor rod
.ge0904	Throttle return spring
.ge0905	Governor spring
.ge0906	Regulating arm
.ge0907	Regulatim arm


## 10. Muffleur / Silencieux



No.	Pièce / Part
.ge1001	Muffleur assly
.ge1002	Muffleur gasket
.ge1003	Exhaust valve tube
.ge1004	Exhaust tube gasket
.ge1005	Smoke deflector


## 11. Fuel tank / Réservoir de carburant

GE 4.0 to 15HP



No.	Pièce / Part
.ge1101	Fuel tank
.ge1102	Fuel tank joint gasket
.ge1103	Fuel tank joint
.ge1104	Fuel tube
.ge1106	Tube clip
.ge1107	Gas cap gasket
.ge1110	Gas cap
.ge1111	Fuel tank filter

## 12. Flywheel / Volant



No.	Pièce / Part
.ge1201	Flywheel comp
.ge1202	Flywheel comp
.ge1203	Cooling fan
.ge1204	Starter pulley
.ge1205	Flywheel nut
.ge1206	Ignition coil
.ge1207	Diode
.ge1208	Stop switch
.ge1209	Oil sensor
.ge1210	Charging coil
.ge1211	Starting motor assly
.ge1212	Key control assly